

Unseen Emissions:

The Carbon Footprint of Knee Arthroscopy

Shannon Tse BMBS, Frank Sierra BS, Katherine Guo BS, Lydia McKeithan MD, Robin Aldwinckle BMBS, Cassandra Lee MD, Zachary Lum DO

University of California, Davis, Sacramento, CA, USA



Faculty Disclosure Information

- Cassandra Lee:
 - Speaker for Genzyme, Johnson & Johnson
 - Board of directors member for AAOS, AOSSM, AANA
 - All relevant financial disclosures have been mitigated
- The other authors have no disclosures







BACKGROUND

- US health sector: 8.5% of nation's carbon emissions
- Environmental sustainability in orthopaedic surgery is an increasing area of interest
- Arthroscopic partial meniscectomy (APM) most common orthopaedic procedure in the US (>500,000 cases annually)

AIM: Quantify the carbon dioxide equivalent emissions (CO2e) of APM







METHODS

Lighting Anesthesia - Sevoflurane **HVAC** - Time per case - Average flow rate 20ml/hr - Machine **Carbon footprint** (kgCO2e) Conversions per US EPA Waste Arthroscopy - Weighed per case - Recyclable tower paper/plastic - Contaminated waste **Sterilization** process - 3 trays for 1.5hrs

- Isolated APM cases included
- OR measured to be 528sq ft.
 - **Energy consumption** estimated using institutional data & manufacturer manuals
 - **Energy calculations** made using average time per case



RESULTS

- 10 APM cases included
- Mean anesthesia time = $73.4 \text{ mins} \pm 10.4$
- Mean total waste = $15.7lb \pm 4.5 (7.1kg \pm 2.0)$
- Mean recyclable paper/plastic waste = 2.0lb ± 1.9 (0.9kg ± 0.9)
- Mean contaminated waste = $13.8lb \pm 2.7$ (6.2kg ± 1.2)
- No waste was actually recycled








Mean Carbon Emissions Per Arthroscopic Partial Meniscectomy				
Category		Units per case	kgCO2e*	% of total case kgCO2e
Anesthesia	Sevoflurane	20ml/hr	4.77	13.67%
	Anesthesia Machine	2.94kWh	0.70	2.01%
HVAC	Heating, ventilation, air-			
	conditioning	12.37kWh	2.90	8.31%
Lighting	Lighting	2.37kWh	0.56	1.60%
Waste	Total solid waste	7.13kg	25.0	71.55%
Sterilization	Steam sterilizer	0.30kWh	0.07	0.20%
Arthroscopy Tower	Pump, camera, shaver			
	system, monitors	3.91kWh	0.93	2.66%
Total			34.90	100%
*Calculated using the US EPA Greenhouse Gases Equivalencies calculator				
All values based on average case time of 73.4mins in a 528sg ft OR				





RESULTS

- Based on 500,000 cases annually = 17452 metric tons CO2e
- Equivalent to CO2/greenhouse gas emissions from:



Equivalent to carbon sequestered by:











CONCLUSION

- 35kgCO2e generated per APM
- Main contributor of carbon emissions was waste
- To reduce emissions and the overall carbon footprint:
- 1) Optimize waste disposal processes
- 2) Increase recycling
- 3) Develop appropriate reusable options







REFERENCES

- 1. Eckelman MJ, Huang K, Lagasse R, Senay E, Dubrow R, Sherman JD. Health Care Pollution And Public Health Damage In The United States: An Update. *Health Affairs*. 2020;39(12):2071-2079.
- 2. Phoon KM, Afzal I, Sochart DH, Asopa V, Gikas P, Kader D. Environmental sustainability in orthopaedic surgery. *Bone Jt Open.* 2022;3(8):628-640.
- 3. Kim S, Bosque J, Meehan JP, Jamali A, Marder R. Increase in Outpatient Knee Arthroscopy in the United States: A Comparison of National Surveys of Ambulatory Surgery, 1996 and 2006. *JBJS*. 2011;93(11):994.
- 4. US EPA O. Greenhouse Gas Equivalencies Calculator. August 28, 2015. Accessed February 24, 2025. https://www.epa.gov/energy/greenhouse-gas-equivalencies-calculator

