



ISAKOS
CONGRESS
2025



MUNICH
GERMANY
June 8-11

A Novel Method for Evaluating the Effect of a Lateral Meniscus Posterior Root Tear on the Loaded Mechanics of a Human Cadaveric Knee's Lateral Compartment

Parth Lodhia, MD FRCSC

Co-Authors: Edward Hoptoncann, Jordan Broberg, Andrew Yung, Kirsten Bale, and David Wilson

University of British Columbia, Vancouver, Canada



THE UNIVERSITY
OF BRITISH COLUMBIA

Faculty Disclosure Information



ISAKOS
CONGRESS
2025



MUNICH
GERMANY
June 8-11

- My disclosures are:
 - Speaker for Arthrex
 - Support received from Ossur
 - Editorial or Governing board of Arthroscopy
 - Board of Directors member for:
 - Canadian Orthopaedic Association
 - International Society of Arthroscopy, Knee Surgery, and Orthopaedic Sports Medicine
 - International Society of Hip Arthroscopy (ISHA)



THE UNIVERSITY
OF BRITISH COLUMBIA

LMPRTs Change Knee Mechanics




ISAKOS
CONGRESS
2025




MUNICH
GERMANY
June 8-11


- Lateral meniscus posterior root tears (LMPRTs) change knee mechanics¹⁻³
 - Increases cartilage degeneration and can lead to knee osteoarthritis (OA)
- LMPRT repair can restore contact pressures and areas to intact values¹⁻³
 - Demonstrated in multiple biomechanical cadaver studies



Intact



LMPRT



Repaired

Effect on Specific Tissues?





ISAKOS
CONGRESS
2025




MUNICH
GERMANY
June 8-11

- **Outstanding Question:** How are the mechanics *within* the joint tissues altered following a LMPRT and subsequent repair?
 - Important to answer because increases in cartilage strain are known to lead to cartilage degeneration and eventual OA⁴
- Measuring cartilage strain together with meniscal mechanics could:
 - Highlight the role of the meniscus in protecting the knee from OA
 - Reveal how LMPRTs disrupt meniscal function and worsen cartilage mechanics
 - Demonstrate the efficacy of LMPRT repair at restoring knee tissue mechanics

Early OA



Late OA



Study Objectives



ISAKOS
CONGRESS
2025



MUNICH
GERMANY
June 8-11

- **Primary Objective:** To design a novel method for comprehensively investigating tissue mechanics in loaded human cadaver knee lateral compartments
 - Must be able to measure mechanics of femoral cartilage, tibial cartilage, and menisci
 - Needs to be capable of measuring mechanics for specimens with intact, torn, and repaired lateral menisci
- **Future Goal:** To evaluate loaded tissue mechanics in specimens before and after an artificially created LMPRT, and subsequent LMPRT repair



THE UNIVERSITY
OF BRITISH COLUMBIA

Ultra High Field MRI



ISAKOS
CONGRESS
2025




MUNICH
GERMANY
June 8-11

- Ultra high field magnetic resonance imaging (MRI) can be used to visualize cartilage and menisci
 - Acquire high enough resolution images to measure cartilage strain, meniscal extrusion, etc.



9.4 Tesla MRI Scanner

**Specimens
placed in this
small hole**



**Example coronal images of the same knee
specimen acquired with 9.4T MRI scanner**

Specimen Preparation



ISAKOS
CONGRESS
2025




MUNICH
GERMANY
June 8-11

- Lateral compartments were isolated while preserving lateral meniscus roots
 - Had to isolate lateral compartment so specimen could fit in the ultra high field MRI scanner




Collected knee



Parallel sawing



Knee slab from sawing



Final prepared lateral compartment



THE UNIVERSITY
OF BRITISH COLUMBIA

MRI-Compatible Loading Device




ISAKOS
CONGRESS
2025



MUNICH
GERMANY
June 8-11

- Compressive load applied to lateral knee compartment by a MRI-compatible pneumatic loading device⁵



THE UNIVERSITY
OF BRITISH COLUMBIA

Study Protocol




ISAKOS
CONGRESS
2025



MUNICH
GERMANY
June 8-11

Intact Meniscus


Unloaded




2 hours of
loading



Loaded




Create the LMPRT and image
again the following day



LMPRT

Unloaded



2 hours of
loading



Loaded



Repair
LMPRT and
repeat



THE UNIVERSITY
OF BRITISH COLUMBIA

Image Segmentation




ISAKOS
CONGRESS
2025




MUNICH
GERMANY
June 8-11


- Joint tissues in acquired images are segmented for evaluating mechanics
 - Ex. Cartilage strain can be measured by comparing unloaded to loaded segmentations



Segmented image



3D reconstruction of
knee specimen



Unloaded and loaded tibial
cartilage segmentations for
measuring axial strain



THE UNIVERSITY
OF BRITISH COLUMBIA


Strain Maps





ISAKOS
CONGRESS
2025




MUNICH
GERMANY
June 8-11



n=6



n=6



Maximum compressive strain in contact area increases after LMPRT in both:

- Femoral cartilage
 - 3% increase
 - $p=0.013$
- Tibial cartilage
 - 5% increase
 - $p=0.010$



THE UNIVERSITY
OF BRITISH COLUMBIA

Conclusion



ISAKOS
CONGRESS
2025





MUNICH
GERMANY
June 8-11

- Developed a method for comprehensively analyzing tissue mechanics in lateral knee
 - Able to assess impact of LMPRTs and repairs on cartilage and meniscal mechanics

Future Goals:

- Evaluate the mechanics of the meniscus⁶ (i.e. extrusion)
 - Explore how meniscal mechanics impact cartilage strain
- Perform LMPRT repairs and repeat loaded imaging protocol
 - Determine whether repairs can restore meniscal function and protect cartilage from large focal strains



THE UNIVERSITY
OF BRITISH COLUMBIA

References



ISAKOS
CONGRESS
2025



MUNICH
GERMANY
June 8–11

1. LaPrade, C. M. *et al.* Altered Tibiofemoral Contact Mechanics Due to Lateral Meniscus Posterior Horn Root Avulsions and Radial Tears Can Be Restored with in Situ Pull-Out Suture Repairs. *JBJS* **96**, 471 (2014).
2. Perez-Blanca, A. *et al.* Comparative Biomechanical Study on Contact Alterations After Lateral Meniscus Posterior Root Avulsion, Transosseous Reinsertion, and Total Meniscectomy. *Arthroscopy* **32**, 624–633 (2016).
3. Forkel, P. *et al.* Biomechanical consequences of a posterior root tear of the lateral meniscus: stabilizing effect of the meniscofemoral ligament. *Arch. Orthop. Trauma Surg.* **133**, 621–626 (2013).
4. Carter, D. R. *et al.* The mechanobiology of articular cartilage development and degeneration. *Clin. Orthop. Rel. Res.* **427**, S69–S77 (2004).
5. Küpper, J. C., Sullivan, E. S., Coope, R. J. N. & Wilson, D. R. Design of a double acting pneumatic cartilage loading device for magnetic resonance imaging. *J. Mech. Behav. Biomed. Mater.* **142**, 105810 (2023).
6. Broberg, J. S. & Wilson, D. R. MR imaging methods to study meniscal position and mechanics. *Osteoarthr. Imaging* **4**, 100222 (2024).



THE UNIVERSITY
OF BRITISH COLUMBIA